



PROGRAM YOUR GENIE REMOTE:

For use with Genie HD DVRs (model HR44 or above), DIRECTV Genie Mini Clients (model C41 or above) and RVU-Enabled televisions.

- » Select **SETTINGS & HELP**
SETTINGS
REMOTE CONTROL
- » Select **IR/RF SETUP**
- » Press the Down Arrow to highlight RF.
- » Press **SELECT**

- » Select **CONTINUE**
- » Complete by following on-screen prompts.

For instructions on how to program your remote to an RVU-enabled television, visit directv.com/rvu.

Each DirecTV remote is paired to work with a specific TV. Numbers on the remote and the TV identify the proper remote. Do not remove a remote from it's assigned TV.