



Additional functions vary. Look for on-screen prompts.

## PROGRAM YOUR REMOTE:

Your new DIRECTV® Universal Remote can control your entire entertainment system—TVs, DVD players, VCRs and stereo systems.

## For SD Receivers:

- » Press the **MENU** button
- » Select **PARENTAL, FAV'S & SETUP**
- SYSTEM SETUP**
- REMOTE CONTROL**

## For HD Receivers:

- » Press the **MENU** button
- » Select **SETTINGS & HELP**
- SETTINGS**
- REMOTE CONTROL**

Each DirecTV remote is paired to work with a specific TV. Numbers on the remote and the TV identify the proper remote. Do not remove a remote from its assigned TV.